TFT LCD CAR MONITOR

Operating instructions

NOTICE: Please read the user manual carefully before using this product

Provision

Performance Parameters

Screen size:7"
Display format:16:9
Video system: NTSC/PAL/SECAM
Power supply: DC 12V±10%
Power consumption:8W
Operating temperature:0℃-50℃C
Storage temperature:-20℃ -60℃
Resolution : 480(W)XRGBX234(H)
Product size:385mm(L)X150mm(W)X26mm(H)
N.W.:900G
Supports OSD control
AV1/AV2 two way input
Picture can be changed up/down ,left/right.
Viewing angle can be adjusted
Can be connected to the in-car camera system for driver rear-view (camera not included)
Timer function
Blue screen background

Kit contents

Car monitor Unit	1PC
Remote Control	1PC
6 pin male cable	1PC
Bracket	1PC
User Manual	1SET

Dear User

Congratulations on your selection of the revolving roof mounted car LCD series. We appreciate your purchase of our product. For maximum enjoyment and prolonged life of this unit, we strongly recommend you read this owner's manual in detail before attempting to operate the unit. Please retain this manual for future reference.

The unit you have purchased has the following advantages

1、Radiation shielded
2、Power saving
3、High clarity of LCD screen
4、High Brightness/contrast
5、Wide view angle
6、Quick response time
7、On Screen Display (OSD) and Infrared Remote Control
8、Multiple video/audio cabling options i.e.: VCD/DVD, portable video camera, webcam, GPS and portable electronic games

WARNING

This unit is not intended for installation in the front driver/passenger area where it may be seen by the driver. Installation of this unit where it may impair the driver's concentration is dangerous. The manufacturer or retailer assumes no responsibility for failing to obey the above warnings.To reduce the risk of electric shock, please do not expose this unit to rain, moisture or attempt to open the unit. There are no user serviceable parts inside the unit.

Caution:

1. Please read these instructions carefully before operating the unit and observe the relevant warnings.
2. Please keep away from moisture and direct sunlight.
3. Do not attempt to disassemble or remodel the unit yourself to avoid electric shock.
4. Please clean the display with a dry and soft cloth.Do not clean the display with any alcohol or chemical cleanser.
5. Please ask a qualified engineer to install the unit.
6. Do not try to recharge the remote control battery.
7 Please keep the remote control battery away from children.
8. The display may sometimes show pixels (light dots or dark dots) during use. This is normal and does not indicate any malfunction.

Provision

Functionality

1、IR transmitter: transmitter frequency (left) 2.3MHZ,transmitter frequency (right) 2.8MHZ
2、OSD function
3、Support PAL/NTSC/SECAM system
4、Blue panel function: if no signal, the panel will be auto-shift to blue mode
5、Up down/ left right revolving
6、When the unit has no signal, the monitor will auto-shift blue screen and in few minutes, the monitor will be auto-closed

Appearance & Functions



Instruction for function keys

1.Analog function (-)
2.V1/V2
3.Power on/off
4.R/C sensor
5.Menu
6.Analog function (+)
7.Bearing (up/down, left/right)
8.TFT LCD display

Method of wiring



operating instruction

Press " MENU" once,the monitor will display as blow:
press "◀ " "▶"or"+ " "- " to make adjustment.

BRIGHT 50
CONTRAST 50
COLOR 50
ZOOM 16:9
SYSI
SLEEP 0
ENGLISH 中文

Remote control



1.Power:
Press this button for power On or Off.
2.Video Select:
Press this button to switch Video 1 orVideo 2 inputs.
3.Menu:
Enter to function menu
4."◀" and "▶":
Navigate through the various menu options
5.Reverse:
up down/left right revolving with diagram

Connect drawing



Maintenance Term

A:Any natural damages in warranty period will be maintained free of charge by our company

B: Any maintenance for disassemble self-assertively and damage over the warranty period should pay relative charge.

C: The quality problem will be maintained free of charge by our any chain store according to maintenance card in guarantee time.

D. The damage for TFT LCD display isn't in maintenance range. We will ask for the cost for change.

■Our company will remain the explaining right for above Maintenance Term.

Provision